

## Nabaztag abroad: anything I need to know?

### Will Nabaztag work in another country?

---

Nabaztag works in any location in the world.  
Wherever you may be, you can enjoy all of the services offered through the [www.nabaztag.com](http://www.nabaztag.com) website.

And better, most of the services are international.  
Nabaztag speaks English and French; the English version of the website is here:  
<http://www.nabaztag.com/vl/FR/lang.jsp?lang=2>

For the moment, you can only send SMS and phone messages from France.

And finally, your Nabaztag works on 110 volts, and complies with both CE and US standards.

**An international version of the website is available;** click here:

**<http://www.nabaztag.com/vl/FR/lang.jsp?lang=2>**

### What services are available from abroad?

---

Wherever you live, Nabaztag will work, because it's connected to the Internet.

Two of the services we offer apply to Paris only: Air Quality and Paris Traffic.

We are working on ways to extend these services to other cities.  
Other services and message functions are fully universal.

We're also going to develop specific services for countries outside France, starting with new cities with a weather forecast.

## I live in another time zone: will it work?

---

Yes, you'll just need to tell your Nabaztag where you live: he'll adjust to your local time.

This is where you can tell him the time:

**[http://www.nabaztag.net/vl/FR/account\\_perso.jsp](http://www.nabaztag.net/vl/FR/account_perso.jsp)**

Oh, and Nabaztag knows about Daylight Saving Time, too.

## Available languages.

---

Nabaztag speaks French and English.

Nabaztag speaks French with a woman's voice, and English with a man's voice.

The synthetic voices used for "I can read" messages are female in French, and male or female in English.

## Getting connected

---

Nabaztag can connect to any Wi-Fi network, anywhere in the world.

## Do I need a voltage adapter?

---

Nabaztag plugs into the mains, and complies with both CE and US standards. You can use a regular adapter with 110 Volt support to plug in your Nabaztag.